


# PRODUCT WARNING

1. Do not lean diffuser during operation.
2. Unplug from mains power when filling or cleaning.
3. Do not empty water from the side which the air vent is located.
4. This appliance is not intended for use by children.
5. If the diffuser is accidentally knocked over during operation, water may enter the internal space. If so, please unplug the diffuser, empty any remaining water and allow to dry for 3 days. If any issues arise please contact your local retailer.

## MELODY Ultrasonic Aroma Diffuser



# TABLE OF CONTENTS:

- A** Function
- B** Operations
- C** Diffuser Setup
- D** Maintenance
- E** Troubleshooting
- F** Warranty



## FUNCTION

Introducing the MELODY Aroma Diffuser: Technology meets Tranquillity to provide you with aromatherapy, music, an alarm clock and calm and soothing illumination all at once.

Utilising the instantaneous benefits of ultrasonic vibrations and Bluetooth, MELODY plays your favourite music in the background and breaks down your fragrance infused water into a microscopic mist that easily dissipates into the atmosphere, leaving your mind, body and soul at peace.



# OPERATIONS

## To Play Music

1. Press "Music" button to switch on/off the Bluetooth function
2. Place your phone within 1 metre of diffuser
3. Search for available devices and select "Aroma Diffuser"
4. Play music from your media player app
5. Adjust volume from your mobile device
6. Change track from your mobile device
7. To connect another mobile device, ensure no other devices are connected with diffuser

## To Set Clock


1. Press "Clock" button to show 12Hr or 24Hr on screen
2. Press "+" or "-" to select between 12hr/24hr format
3. Press "Clock" again to set hour
4. Press "+" or "-" to adjust the hour
5. Press "Clock" to confirm hour setting
6. Press "+" or "-" to adjust the minute
7. Press "Clock" to finish clock setting

## To Set Alarm

1. Press "Alarm" button to show current alarm time on screen
2. Press "+" or "-" to adjust the hour
3. Press "Alarm" to confirm hour setting
4. Press "+" or "-" to adjust the minute
5. Press "Alarm" to finish alarm setting
6. Alarm will beep and start diffuser and light if water is filled
7. Press any button to turn off alarm beeping once it starts

## To Cancel Alarm

1. Press & Hold "Alarm" for 2 seconds until screen shows --:--




Diffuser Operation			
① Power Switch		① Night-light Button	
Left	Off	First	Colour Morphing
	On - Constant	Second	Selectable Colour
	On - 1 hr		
	On - 3 hr		
Right	On - 6 hr	Third	Off



# DIFFUSER SETUP

Product Name:	MELODY Aroma Diffuser
Voltage:	DC 24 v
Power:	16 w
Water Capacity:	360 ml
Mist Output:	30 ml/h
Duration:	9+ hrs Constant
Timer:	On / 1hr / 3hr / 6hr
LED Effect:	Colour Morphing + Selectable Colour

1. Place diffuser on a flat and even surface, clear of any loose or foreign objects.
2. Fill water tank to max level line - 360ml.
3. Replace cover and connect power.
4. Add up to 3-5 drops of essential or fragranced oils.
5. Turn the Power Switch on base unit to activate.
6. Press the Light Button for desired light effect.




Lift & remove  
cover from base




Fill with water up  
to max level line



Add 5-7 drops of  
your favourite oil



Replace cover  
on base unit



Connect Power  
Adaptor



Turn "Power" knob  
to switch on

# D

## MAINTENANCE

To keep your diffuser in great working order, we recommend clean it regularly with Alcyon cleanser.

Alcyon Diffuser Cleanser - Revive and restore your diffuser like new. Run for a 2-hour cycle and eliminate all the residual sediment and harmful particles left over from essential oils which impairs mist output and therapeutic performance. Alcyon Diffuser Cleanser makes it easy to keep your diffuser working like new so you can enjoy all its health benefits and get the full effect and pleasure from essential oil and aromatherapy.

### Directions:


Pour 50 to 100ml of diffuser cleanser into water tank of diffuser depends on its size.

Run diffuser for 2 hours or until all cleanser in the tank has been diffused.

Remove any excess cleanser and rinse water tank thoroughly then wipe it clean with a soft cloth.

Resume normal use as per manufacturers operating instructions.


We recommend that if not in use for a prolonged period, please remove any standing water  
To purchase Alcyon diffuser cleanser, please visit your nearest stockist or [www.alcyon.com.au](http://www.alcyon.com.au)



Unplug diffuser  
from mains power




Lift & remove  
cover



Empty any  
remaining water



Pour Alcyon Diffuser  
Cleanser into water tank



Replace cover and  
wipe exterior



Run diffuser for 2 hours  
then rinse to clean



# TROUBLESHOOTING

Symptom	Possible Cause	Solution
<b>NO MIST</b>	Power not connected	Plug in power adaptor and press mist button to activate
	Insufficient water	Fill tank with water
	Too much water (360ml+)	Tip out excess water
	The mist outlet blocked by water droplets or oil build-up	Clean outlet vent cotton tip
	Poor performance due to dirty	Use Alcyon Diffuser Cleanser
	Cover not seated or sealed properly against base unit	Reseat cover



# WARRANTY CARD

All Alcyon Ultrasonic Diffusers are covered by a limited one year warranty from date of purchase.

Date of purchase: \_\_\_\_ / \_\_\_\_ / \_\_\_\_  
(please keep your receipt with Warranty Card as Proof of Purchase)

Should you be experiencing any issues with your diffusers, please visit [www.alcyon.com.au](http://www.alcyon.com.au) or call 1300 882 332.  
(please have your diffuser on hand when calling)

#### Terms and Conditions:

- A dated receipt is required as Proof of Purchase for warranty purposes.
- This warranty is for operational faults only, and does not cover issues such as breakages or faults arising from misuse.
- Any returned items from customers to Alcyon will be at the consumer's expense and must be accompanied with a RA (Return Authorisation) number issued by Alcyon. Unless a prior arrangement has been made.
- Any goods received without a RA number will not be accepted and returned to the sender.
- The determination of faults is at the discretion of Alcyon Australia, with the item to be either repaired or replaced.
- Return shipping from Alcyon to the customer is to be at Alcyon's expense.

Alcyon Australia  
PO Box 50  
LINFIELD NSW 2070

1300 882 332

[info@alcyon.com.au](mailto:info@alcyon.com.au)