


# PRODUCT WARNING


1. Do not lean diffuser during operation.
2. Unplug from mains power when filling or cleaning.
3. Do not empty water from the side which the air vent is located.
4. This appliance is not intended for use by children.
5. If the diffuser is accidentally knocked over during operation, water may enter the internal space.

If so, please unplug the diffuser, empty any remaining water and allow to dry for 3 days.

If any issues arise please contact your local retailer.




ALCYON



[www.alcyon.com.au](http://www.alcyon.com.au)

# FLAME Ultrasonic Aroma Diffuser



ALCYON

[www.alcyon.com.au](http://www.alcyon.com.au)

# TABLE OF CONTENTS:

- A** Function
- B** Diffuser Setup
- C** Operations
- D** Maintenance
- E** Troubleshooting
- F** Warranty



## FUNCTION

With an innovative and unique design, the FLAME Ultrasonic Aroma Diffuser combines the DNA of both oriental and western cultures to bring you this fashionable diffuser.

Utilising the instantaneous benefits of ultrasonic vibrations, FLAME works silently in the background to break down your fragrance infused water into a microscopic mist that easily dissipates into the atmosphere. Leaving your mind, body and soul at peace.



# B

## SPECIFICATIONS

Product Name:	FLAME Aroma Diffuser
Voltage:	DC 24V
Power:	14 w
Water Capacity:	240 ml
Mist Output:	40 ml/h (High Mist Mode) 20ml/h (Low Mist Mode)
Duration:	6 hrs (High Mist Mode) 10 hrs (Low Mist Mode)
LED Effect:	High/Low/Breathing Mode

Diffuser Operation			
Mist Button		Light Button	
First	High Mist Mode	First	High Light Mode
Second	Low Mist Mode	Second	Low Light Mode
Third	2 Hour Off Timer	Third	Breathing Light Mode
Fourth	4 Hour Off Timer	Fourth	Light Off (or Long Press Anytime)
Fifth	Off (or Long Press Anytime)		


Location of Controls





# OPERATION I


1. Place diffuser on a flat and even surface, clear of any loose or foreign objects.
2. Fill water tank to max level line - 200 to 240 ml.
3. Add up to 3-6 drops of essential or fragranced oils.
4. Replace cover & connect power.
5. Press the Mist Button for desired mist output.
6. Press the Light Button for desired light effect.




1. Connect Power Cord




2. Lift & remove covers from base




3. Fill with water up to max level



4. Add 3-6 drops of your favourite oil



5. Replace outer and inner cover



6. Plug in power adaptor into outlet

# D

## MAINTENANCE

To keep your diffuser in great working order, we recommend using Alcyon Diffuser Cleanser to clean regularly.

Alcyon Diffuser Cleanser - Revive and restore your diffuser like new. Most manufacturers recommend cleaning your diffuser every few weeks to remove impurities. Run for a 2-hour cycle and eliminate all the residual sediment and harmful particles left over from essential oils which impairs mist output and therapeutic performance. Alcyon Diffuser Cleanser makes it easy to keep your diffuser working like new so you can enjoy all its health benefits and get the full effect and pleasure from essential oil and aromatherapy.

To purchase please visit: [www.alcyon.com.au](http://www.alcyon.com.au)



### Directions:

Pour 50 to 100ml of diffuser cleanser into water tank of diffuser depends on its size. Add same amount of water to dilute the cleanser.

Run diffuser for 2 hours or until all cleanser in the tank has been diffused.

Remove any excess cleanser and rinse water tank thoroughly then wipe it clean with a soft cloth.

Resume normal use as per manufacturers operating instructions.

### Ingredients:

Aqua, Potassium Lauroyl Sarcosinate, Potassium Cocoyl Glycinate, peg-6 Caprylic/capric Glycerides, beta-glucan, Dmdm Hydantoin, aroma

### Caution:

For external use only. In case of contact with eyes, flush thoroughly with water. If eye irritation persists, get medical attention. Keep out of reach of children and pets.



# TROUBLESHOOTING

Symptom	Possible Cause	Solution
<b>NO MIST</b>	Power not connected	Plug in power adaptor and press mist button to activate
	Insufficient water	Fill tank with water
	Too much water (240ml+)	Tip out excess water
	The mist outlet blocked by water droplets or oil build-up	Clean outlet vent cotton tip
	Poor performance due to dirty	Clean ultrasonic pad
	Cover not seated or sealed properly against base unit	Reseat cover



# WARRANTY CARD

All Alcyon Ultrasonic Diffusers are covered by a limited one year warranty from date of purchase.

Date of purchase: \_\_\_\_/\_\_\_\_/\_\_\_\_  
(please keep your receipt with Warranty Card as Proof of Purchase)

Should you be experiencing any issues with your diffusers, please visit [www.alcyon.com.au](http://www.alcyon.com.au) or call 1300 882 332.  
(please have your diffuser on hand when calling)

#### Terms and Conditions:

- A dated receipt is required as Proof of Purchase for warranty purposes.
- This warranty is for operational faults only, and does not cover issues such as breakages or faults arising from misuse.
- Any returned items from customers to Alcyon will be at the consumer's expense and must be accompanied with a RA (Return Authorisation) number issued by Alcyon. Unless a prior arrangement has been made.
- Any goods received without a RA number will not be accepted and returned to the sender.
- The determination of faults is at the discretion of Alcyon Australia, with the item to be either repaired or replaced.
- Return shipping from Alcyon to the customer is to be at Alcyon's expense.

Alcyon Australia  
PO Box 50  
LINFIELD NSW 2070

1300 882 332

[info@alcyon.com.au](mailto:info@alcyon.com.au)