PRODUCT WARNING

- 1. Do not lean diffuser during operation.
- 2. Unplug from mains power when filling or cleaning.
- 3. Do not empty water from the side which the air vent is located.
- 4. This appliance is not intended for use by children.
- 5. If the diffuser is accidently knocked over during operation, water may enter the internal space. If so, please unplug the diffuser, empty any remaining water and allow to dry for 3 days. If any issues arise please contact your local retailer.












TABLE OF CONTENTS:

- (A) Function
- **B** Specifications
- C Diffuser Setup
- **D** Maintenance
- **E** Troubleshooting
- **F** Warranty



FUNCTION

With an innovative and unique design, the SOL Ultrasonic Aroma Diffuser combines the DNA of both oriental and western cultures to bring you this fashionable diffuser.

Utilising the instantaneous benefits of ultrasonic vibrations, SOL works silently in the background to break down your fragrance infused water into a microscopic mist that easily dissipates into the atmosphere. Leaving your mind, body and soul at peace.



SPECIFICATIONS

Product Name: Sol Aroma Diffuser

Voltage: DC 24 v Power: 12 w

Water Capacity: 110-120ml Mist Output: 10-15 ml/h

Room Coverage: 15 m²

Duration: 8 hrs [approx]
LED Effect: Transition Colours

+ Selectable

A. Glass Cover

___ 1. Ultrasonic Pad


B. Base Unit —

- 2. Max (120ml) Water Line

3. Exhaust Fan

C. Adaptor - 4. Bi

Diffuser Operation			
①	Mist	LED Effect	
Press Once	On - Active	Transition	
Press Twice	On - Active	Selected Colour	
Press Three times	On - Active	Off	
Press Four times	Off	Off	






DIFFUSER SETUP

- Place diffuser on a flat and even surface, clear of any loose or foreign objects.
- 2. Fill water tank to max level line.
- 3. Add up to 3-5 drops of essential or fragranced oils.
- 4. Press down lightly on glass cover until you hear the button click to activate.

Please take care with the diffuser cover, as it is made from glass and is fragile.



Remove cover from base unit



Connect adaptor to base unit



Fill with water up to max level line







Replace glass



Press down lightly to activate



MAINTENANCE

To keep your diffuser in great working order, we recommend that you clean every week.

- 1. Turn off diffuser and unplug from mains power.
- 2. Remove glass cover.
- 3. Empty any remaining water from tank.
- 4. Wash with a 50/50 mix of vinegar and warm water.
- Clean water tank and around ultrasonic pad with a clean, soft-cotton tip.
- 6. Replace glass cover and clean exterior with clean damp cloth.

We recommend that if not in use for a prolonged period, please remove any standing water

Please take care with diffuser cover, as it is made from glass and is fragile.



Unplug diffuser from mains power



Remove glass cover



Empty any remaining water



Wash with the vinegar mix



Lightly clean water tank and pad



Replace over and



TROUBLESHOOTING

Symptom	Possible Cause	Solution
NO MIST The dr	Power not connected	Plug in power adaptor and press glass cover to activate
	Insufficient water	Fill tank with water
	Too much water (120ml+)	Tip out excess water
	The mist outlet blocked by water droplets or oil build-up	Clean outlet vent cotton tip
	Poor performance due to dirty or aged ultrasonic pad	Clean ultrasonic pad - contact Alcyon for replacement pad
	Glass cover not seated or sealed against base unit	Reseat glass cover



WARRANTY CARD

All Alcyon Ultrasonic Diffusers are covered by a limited one year warranty from date of purchase.

Date of purchase: ____/ ___/ ___ (please keep your receipt with Warranty Card as Proof of Purchase)

Should you be experiencing any issues with your diffusers, please visit www.alcyon.com.au or call 1300 882 332. (please have your diffuser on hand when calling)

Terms and Conditions:

- A dated receipt is required as Proof of Purchase for warranty purposes.
- This warranty is for operational faults only, and does not cover issues such as breakages or faults arising from misuse.
- Any returned items from customers to Alcyon will be at the consumer's expense and must be accompanied with a RA (Return Authorisation) number issued by Alcyon.
- Any goods received without a RA number will not be accepted and returned to the sender.
- The determination of faults is at the discretion of Alcyon Australia, with the item to be either repaired or replaced.
- Return shipping from Alcyon to the customer is to be at Alcyon's expense.

Alcyon Australia PO Box 48 NORTH RYDE BC NSW 1670

1300 882 332

info@alcyon.com.au www.alcyon.com.au