

PRODUCT WARNING

1. Do not lean diffuser during operation.
2. Unplug from mains power when filling or cleaning.
3. Do not empty water from the side which the air vent is located.
4. This appliance is not intended for use by children.
5. Do not touch the light bulb when the lamp is on.
6. Unplg adaptor when you replace light bulb.
7. Do not attempt to fill water into diffuser from the mist output

5. If the diffuser is accidentally knocked over during operation, water may enter the internal space.

If so, please unplug the diffuser, empty any remaining water and allow to dry for 3 days.

If any issues arise please contact your local retailer.



KIYOSHI Ultrasonic Aroma Diffuser




TABLE OF CONTENTS:

- A** Function
- B** Diffuser Setup
- C** Operations 1
- D** Maintenance & Operations 2
- E** Troubleshooting
- F** Warranty





FUNCTION

Introducing the KIYOSHI Aroma Diffuser: Technology meets Tranquillity to provide you with aromatherapy, calm and soothing illumination all at once.


Utilising the instantaneous benefits of ultrasonic vibrations and Himalayan salt, purify and revitalise any home with the next step in holistic wellness. KIYOSHI is the perfect result that two perfect worlds collide!

B

SETUP




1. Take off the top part, salt container, and install the bulb.



2. Plug bulb pins into the small holes on bulb base (NO +/- difference). Then put back salt container.



3. Put the salt into the salt container and then put back top part.




When you install top part, please connect to the correct direction. The "MAX" MARK inside water tank is on back side.




OPERATION I

Product Name:	KIYOSHI Aroma Diffuser
Voltage:	DC 24 v
Power:	20 w
Water Capacity:	150 ml
Mist Output:	25 ml/h
Duration:	6+ hrs Constant
LED Effect:	5 Brightness Level


1. Place diffuser on a flat and even surface, clear of any loose or foreign objects.
2. Fill water tank to max level line - 150ml.
3. Replace cover and connect power.
4. Add up to 4-6 drops of essential or fragranced oils.
5. Press the Mist Button on base unit to activate.
6. Press the Light Button for desired light effect.



1. Take off the outer cover



2. Take off the inner cover



3.Fill water to max line




4.Add 4~6 drops of essential oil


D

MAINTENANCE & OPERATION 2


To keep your diffuser in great working order, we recommend that you clean once a week.




1. Turn off diffuser and unplug from mains power.
2. Remove cover.
3. Empty any remaining water from tank.
4. Wash with a 50/50 mix of vinegar and warm water.
5. Clean water tank and around ultrasonic pad with a clean, soft-cotton tip.
6. Replace cover and clean exterior with clean damp cloth.
7. We recommend that if not in use for a prolonged period, please remove any standing water and pack the salt separately with a sealed bag.



5. Place the inner cover



6. Place the outer cover



7. Connect the power with plug



8. Settings

Power : Touch the button to turn on/off the diffuser.

First touch, diffuser is on.

Second touch, diffuser is off.

Light : Touch the light button repeatedly

to control the salt lamp.

5 levels luminance available from min to max, in the sixth touch, the light is off.

For further Diffuser Maintenance, please visit: www.alcyon.com.au



TROUBLESHOOTING

Symptom	Possible Cause	Solution
NO MIST	Power not connected	Plug in power adaptor and press mist button to activate
	Insufficient water	Fill tank with water
	Too much water (300ml+)	Tip out excess water
	The mist outlet blocked by water droplets or oil build-up	Clean outlet vent cotton tip
	Poor performance due to dirty	Clean ultrasonic pad
	Cover not seated or sealed properly against base unit	Reseat cover



WARRANTY CARD

All Alcyon Ultrasonic Diffusers are covered by a limited one year warranty from date of purchase.

Date of purchase: ____ / ____ / ____
(please keep your receipt with Warranty Card as Proof of Purchase)

Should you be experiencing any issues with your diffusers, please visit www.alcyon.com.au or call 1300 882 332.
(please have your diffuser on hand when calling)

Terms and Conditions:

- A dated receipt is required as Proof of Purchase for warranty purposes.
- This warranty is for operational faults only, and does not cover issues such as breakages or faults arising from misuse.
- Any returned items from customers to Alcyon will be at the consumer's expense and must be accompanied with a RA (Return Authorisation) number issued by Alcyon. Unless a prior arrangement has been made.
- Any goods received without a RA number will not be accepted and returned to the sender.
- The determination of faults is at the discretion of Alcyon Australia, with the item to be either repaired or replaced.
- Return shipping from Alcyon to the customer is to be at Alcyon's expense.

Alcyon Australia
PO Box 50
LINFIELD NSW 2070

1300 882 332

info@alcyon.com.au